



GAMO® BI-POD PARTS & FUNCTIONS




GAMO® BI-POD INSTALLATION & OPERATION INSTRUCTIONS













3. The Gamo Bi-Pod's legs feature two positions, down for bipod shooting and up for storage or easier cocking of your gun. To unlock the legs simply depress the Swivel Lock Joint Release Latch and reposition the leg.

